



GWM

GWM TANK 300 Petrol Service Schedule



Months	12	24	36	48	60	72	84	96	108	120
Mileage *1000 km	10	25	40	55	70	85	100	115	130	145
Engine oil	R	R	R	R	R	R	R	R	R	R
Engine oil drain plug washer	R	R	R	R	R	R	R	R	R	R
Engine oil filter	R	R	R	R	R	R	R	R	R	R
Fuel Filter	R	R	R	R	R	R	R	R	R	R
In throttle valve (clean in poor fuel environments)		I		I		I		I		I
In intercooler hoses (clean in poor fuel environments)		I		I		I		I		I
Spark plug			R			R			R	
Generator & water pump belt	Replace every 100,000 km									
Transfer case oil*	Replace every 45,000 km (suggested first occurrence at 36m/40k)									
Front & Rear Differential gear oil*	Replace at 45,000 km (suggested first occurrence at 36m/40k)									
Tension of important fasteners	I	I	I	I	I	I	I	I	I	I
Disc brake front and rear	I	I	I	I	I	I	I	I	I	I
Tyre pressure and wear	I	I	I	I	I	I	I	I	I	I
Four-wheel alignment (tyre visual and road-test)	I	I	I	I	I	I	I	I	I	I
Ball joint and dust cover	I	I	I	I	I	I	I	I	I	I
Air cleaner element	I	R	I	R	I	R	I	R	I	R
Air conditioner filter element		R		R		R		R		R
Carbon Canister filter cleaning		C		C		C		C		C
Engine coolant				R				R		
Brake fluid			R			R			R	
Radiator (appearance)	I	I	I	I	I	I	I	I	I	I
Intercooler (appearance)	I	I	I	I	I	I	I	I	I	I
Battery & Connections	I	I	I	I	I	I	I	I	I	I
Sunroof	I	I	I	I	I	I	I	I	I	I
Sunroof drain	I	I	I	I	I	I	I	I	I	I
Sign of oils / fluid leakage	I	I	I	I	I	I	I	I	I	I
Lights and warning device operation	I	I	I	I	I	I	I	I	I	I
Parking brake operation	I	I	I	I	I	I	I	I	I	I
Recall / Service Campaign check	I	I	I	I	I	I	I	I	I	I
Road test quality control	I	I	I	I	I	I	I	I	I	I

R =Replace, I = Inspect, C= Clean

* Denotes items that may need to shorten in interval in the instance of Severe Duty/Driving Conditions

GWM Tank 300 Petrol Service Schedule



GWM

GWM TANK 300 Diesel Service Schedule



Months	12	24	36	48	60	72	84	96	108	120
Mileage *1000 km	10	25	40	55	70	85	100	115	130	145
Engine oil*	R	R	R	R	R	R	R	R	R	R
Engine oil drain plug washer*	R	R	R	R	R	R	R	R	R	R
Engine oil filter*	R	R	R	R	R	R	R	R	R	R
Engine Fuel Filter*	R	R	R	R	R	R	R	R	R	R
Throttle valve, EGR valve and cooler	Standard Service									
	Severe Duty Interval									
Tensioner pulley/Idler pulley/Belt pulley	I	I	I	I	I	I	I	I	I	I
Engine timing belt	Replace first at 70,000 km, then every 75,000km.									
Generator belt	Replace every 100,000 km, then every 105,000km.									
Transmission oil	Replace every 150,000 km or 72 Months whichever occurs first.									
Pressure filter	Replace every 150,000 km or 72 Months whichever occurs first.									
Transfer case oil	First replace at 40,000 km or 36Months, then replace every 45,000 km									
Front main reducing gear oil	First replace at 40,000 km or 36Months, then replace every 100,000 km or 48Mths whichever occurs first.									
Rear main reducing gear oil	First replace at 40,000 km or 36Months, then replace every 100,000 km or 48Mths whichever occurs first.									
Important bolts and nuts	I	I	I	I	I	I	I	I	I	I
Disc brake	I	I	I	I	I	I	I	I	I	I
Tire pressure and wear	I	I	I	I	I	I	I	I	I	I
Ball joint and dust cover	I	I	I	I	I	I	I	I	I	I
Air cleaner element	I	R	I	R	I	R	I	R	I	R
Air conditioner filter element	I	R	I	R	I	R	I	R	I	R
Engine coolant	Replace every 80,000 km or 48Mths whichever occurs first.									
Brake fluid	I	I	R	I	I	R	R	I	R	I
Engine coolant overflow tank level	I	I	I	I	I	I	I	I	I	I
Radiator(appearance)	I	I	I	I	I	I	I	I	I	I
Intercooler (appearance)	I	I	I	I	I	I	I	I	I	I
Inspect tyre pressures and wear	I	I	I	I	I	I	I	I	I	I
Battery	I	I	I	I	I	I	I	I	I	I
Panoramic sunroof	I	I	I	I	I	I	I	I	I	I
Sunroof drain	I	I	I	I	I	I	I	I	I	I
Rear windshield sliding window	I	I	I	I	I	I	I	I	I	I
Parking braking*	I	I	I	I	I	I	I	I	I	I
Leakage*	I	I	I	I	I	I	I	I	I	I
Check for campaigns	I	I	I	I	I	I	I	I	I	I
Lights*	I	I	I	I	I	I	I	I	I	I

R =Replace, I = Inspect, C= Clean

* Denotes items that may need to shorten in interval in the instance of Severe Duty/Driving Conditions



GWM

GWM TANK 300 Hi4T (PHEV) Service Schedule



Months		12	24	36	48	60	72	84	96	108	120
Mileage *1000 km		10	25	40	55	70	85	100	115	130	145
Engine oil*		R	R	R	R	R	R	R	R	R	R
Engine oil drain plug washer*		R	R	R	R	R	R	R	R	R	R
Engine oil filter*		R	R	R	R	R	R	R	R	R	R
Spark Plug						R				R	
Throttle valve, EGR valve and cooler	Standard Service	I	I	I	I	I	I	I	I	I	I
	Severe Duty Interval		C		C		C		C		C
Ribbed belt		I	I	I	I	I	I	I	I	I	R
Transmission oil*	Replace every 150,000 km or 72 Months whichever occurs first.										
Pressure filter*	Replace every 150,000 km or 72 Months whichever occurs first.										
Transfer case oil	First replace at 40,000 km or 36Months, then replace every 45,000 km										
Front main reducing gear oil	First replace at 40,000 km or 36Months, then replace every 100,000 km or 48Mths whichever occurs first.										
Rear main reducing gear oil	First replace at 40,000 km or 36Months, then replace every 100,000 km or 48Mths whichever occurs first.										
Important bolts and nuts		I	I	I	I	I	I	I	I	I	I
Disc brake		I	I	I	I	I	I	I	I	I	I
Tyre pressure and wear		I	I	I	I	I	I	I	I	I	I
Ball joint and dust cover		I	I	I	I	I	I	I	I	I	I
Air cleaner element		I	R	I	R	I	R	I	R	I	R
Air conditioner filter element			R		R		R		R		R
Carbon canister filter*				C			C			C	
Engine coolant	Replace every 80,000 km or 48Mths whichever occurs first.										
Brake fluid		I	I	R	I	I	R	I	I	R	I
Radiator(appearance)		I	I	I	I	I	I	I	I	I	I
Tyre rotate		I	I	I	I	I	I	I	I	I	I
Battery		I	I	I	I	I	I	I	I	I	I
Sunroof*		I	I	I	I	I	I	I	I	I	I
Sunroof drainage pipe		I	I	I	I	I	I	I	I	I	I
EV System Coolant	Replace every 100,000 km or 72Mths whichever occurs first.										
High temperature overflow tank level		I	I	I	I	I	I	I	I	I	I
Low temperature overflow tank level		I	I	I	I	I	I	I	I	I	I
Door Handle		I	I	I	I	I	I	I	I	I	I
Vehicle body condition					I		I		I		I
Power battery pack (appearance)			I		I		I		I		I
Power battery high/low voltage connectors			I		I		I		I		I
Power battery SOH parameters			I		I		I		I		I
High voltage harness system		I	I	I	I	I	I	I	I	I	I
Charging port		I	I	I	I	I	I	I	I	I	I
Derain pipe of charging port		I	I	I	I	I	I	I	I	I	I
Electric drive assembly system		I	I	I	I	I	I	I	I	I	I
High voltage power supply system		I	I	I	I	I	I	I	I	I	I

R =Replace, I = Inspect, C= Clean

* Denotes items that may need to shorten in interval in the instance of Severe Duty/Driving Conditions



GWM

GWM Tank 300 HEV Built Apr 25 or Before Service Schedule



Months	12	24	36	48	60	72	84	96	108	120
Mileage *1000 km	10	25	40	55	70	85	100	115	130	145
Engine oil*	R	R	R	R	R	R	R	R	R	R
Washer - Drain plug of oil pan*	R	R	R	R	R	R	R	R	R	R
Engine oil filter*	R	R	R	R	R	R	R	R	R	R
Fuel filter*	R	R	R	R	R	R	R	R	R	R
Throttle valve		I		I		I		I		I
Interior and connection pipes of intercooler		I		I		I		I		I
Spark plug			R			R			R	
Transmission Pressure Filter			R			R			R	
Water pump belt	Replace every 100,000 km									
9HAT Oil*	First replace at 40,000km/36Mths, then every 45,000Km/36Mths									
Transfer case oil*	First replace at 40,000km/36Mths, then every 45,000Km/36Mths									
Differential gear oil* (front and rear)	First replace at 40,000km/36Mths, then every 45,000Km/36Mths									
Important bolts and nuts	I	I	I	I	I	I	I	I	I	I
Disc brake	I	I	I	I	I	I	I	I	I	I
Tyre pressure and wear	I	I	I	I	I	I	I	I	I	I
Wheel transposition	I	I	I	I	I	I	I	I	I	I
Four-wheel alignment (tyre visual and road-test)	I	I	I	I	I	I	I	I	I	I
Ball joint and dust cover		I		I		I		I		I
Air filter element*	I	R	I	R	I	R	I	R	I	R
Air conditioner filter*		R		R		R		R		R
Radiator (appearance)	I	I	I	I	I	I	I	I	I	I
Intercooler (appearance)	I	I	I	I	I	I	I	I	I	I
Carbon canister filter*		C		C		C		C		C
Engine coolant	Replace every 60,000 km/48Mths									
Power battery pack coolant	Replace every 60,000 km/48Mths									
Brake fluid	Replace every 45,000Km/36Mths									
Sunroof drainage pipe	I	I	I	I	I	I	I	I	I	I
Battery and Connection	I	I	I	I	I	I	I	I	I	I
Leakage(oil/water/electricity/air)	I	I	I	I	I	I	I	I	I	I
Lighting	I	I	I	I	I	I	I	I	I	I
Power Battery Bolts between power pack and chassis		I		I		I		I		I
Power battery pack(appearance)		I		I		I		I		I
Power battery pack high/low voltage connector		I		I		I		I		I
Power battery pack SOH parameter		I		I		I		I		I
Parking brake operation	I	I	I	I	I	I	I	I	I	I
Recall / Service Campaign check	I	I	I	I	I	I	I	I	I	I
Road test quality control	I	I	I	I	I	I	I	I	I	I

R =Replace, I = Inspect, C= Clean

* Denotes items that may need to shorten in interval in the instance of Severe Duty/Driving Conditions

GWM Tank 300 HEV Service Schedule



GWM Tank 300 HEV Built May 25 or After Service Schedule



Months	12	24	36	48	60	72	84	96	108	120
Mileage *1000 km	10	25	40	55	70	85	100	115	130	145
Engine oil*	R	R	R	R	R	R	R	R	R	R
Washer - Drain plug of oil pan*	R	R	R	R	R	R	R	R	R	R
Engine oil filter*	R	R	R	R	R	R	R	R	R	R
Fuel filter*	R	R	R	R	R	R	R	R	R	R
Throttle valve		I		I		I		I		I
Interior and connection pipes of intercooler		I		I		I		I		I
Spark plug			R			R			R	
Water pump belt	Replace every 100,000 km									
9HAT Oil*	First replace at 55,000km/48 Mths, then every 60,000Km/48 Mths									
Transmission Pressure Filter										
Transfer case oil*	First replace at 40,000km/36Mths, then every 45,000Km/36Mths									
Differential gear oil* (front and rear)	First replace at 55,000km/48 Mths, then every 60,000Km/48 Mths									
Important bolts and nuts	I	I	I	I	I	I	I	I	I	I
Disc brake	I	I	I	I	I	I	I	I	I	I
Tyre pressure and wear	I	I	I	I	I	I	I	I	I	I
Wheel transposition	I	I	I	I	I	I	I	I	I	I
Four-wheel alignment (tyre visual and road-test)	I	I	I	I	I	I	I	I	I	I
Ball joint and dust cover		I		I		I		I		I
Air filter element*	I	R	I	R	I	R	I	R	I	R
Air conditioner filter*		R		R		R		R		R
Radiator (appearance)	I	I	I	I	I	I	I	I	I	I
Intercooler (appearance)	I	I	I	I	I	I	I	I	I	I
Carbon canister filter*		C		C		C		C		C
Engine coolant	First replace at 55,000km/48 Mths, then every 60,000Km/48 Mths									
Power battery pack coolant	First Replace at 100,000Km / 84Mths, then every 105,000Km / 84Mths									
Brake fluid	First replace at 40,000Km/36Mths, then every 45,00kms / 36 Mths									
Sunroof drainage pipe	I	I	I	I	I	I	I	I	I	I
Battery and Connection	I	I	I	I	I	I	I	I	I	I
Leakage(oil/water/electricity/air)	I	I	I	I	I	I	I	I	I	I
Lighting	I	I	I	I	I	I	I	I	I	I
EV Battery Bolts between EV pack and chassis		I		I		I		I		I
EV battery pack(appearance)		I		I		I		I		I
EV battery pack high/low voltage connector		I		I		I		I		I
EV battery pack SOH parameter		I		I		I		I		I
Parking brake operation	I	I	I	I	I	I	I	I	I	I
Recall / Service Campaign check	I	I	I	I	I	I	I	I	I	I
Road test quality control	I	I	I	I	I	I	I	I	I	I

R =Replace, I = Inspect, C= Clean
 * Denotes items that may need to shorten in interval in the instance of Severe Duty/Driving Conditions

GWM Tank 300 HEV Service Schedule



GWM Servicing - Severe duty Driving Conditions

As with all vehicles, Severe Duty Driving Conditions requires additional maintenance requirements to ensure your vehicle is running at its best. Conditions may vary depending on the operation of your vehicle, so whilst the below list is a good indicator of Severe or Heavy-Duty Driving conditions, it is always best to refer to your local GWM Authorised Service Location for further assistance and advice.

To find your closest location, please follow this link:

Severe Duty Driving Conditions include but are not limited to:

- Repeated short trips of less than 16km when outside temperatures remain below freezing or normal vehicle operating temperature is not achieved.
- Repeated extensive periods of idling, such as use as a taxi, rideshare, door-to-door delivery, or other uses that include extended periods of idling.
- Operating the vehicle in off-road or dusty conditions, including but not limited to unpaved roads, dusty roads, sandy roads etc.
- Repeatedly towing a trailer or caravan, using the vehicle with a rooftop carrier installed, or carrying maximum vehicle loads.
- Repeated use of "Launch Control" mode in applicable vehicles.
- Hard Driving, such as track use or driving with frequent hard accelerations.

If you find your vehicle meeting one or more of the above conditions, please shorten your service interval, apply any "Severe Duty" Service conditions to your vehicle, and/or, carry out an interim service on your vehicle. Service actions completed as "Severe Duty Driving" are not included in Capped Price Servicing and are at an additional expense to the customer.

You may also find your vehicle is subject to specific "Severe Duty service requirements". Please refer to your service schedule for more information.

H6GT PHEV

- Replace Rear Electric Drive Axle Oil every 60,000kms if vehicle driven under Severe Duty Conditions.

Diesel Variant Vehicles

- GWM recommends inspection of Throttle Valve and EGR Valve and Cooler every service. Under Severe Duty Conditions GWM recommends these components are cleaned of carbon deposits when required.

GWM would also like to remind drivers that routine checks and vehicle cleaning conducted by the driver/owner are essential to ensuring your vehicle is running at its best.

This includes checking the oil level, the washer fluid level, and ensuring your vehicle is regularly and thoroughly cleaned to avoid any damage to paint and/or to avoid rust when vehicles are operated in and/or reside in "salty" areas such as beachside areas, river areas, etc.

GWM refers the customer to their owner's handbook for more information about their vehicle, its maintenance and checks they can do to ensure their vehicle is running smoothly.